

# TINTING OILS WITH TOCKAY DRY PIGMENTS



**1.** Pour some of the oil into a small container and add the required amount of pigment.



**2.** Mix the pigment thoroughly with a wooden stirring stick to produce a smooth, viscous mass.



**3.** Stir vigorously to obtain a homogeneous consistency.



**4.** Then add the mixture to the required amount of oil.



**5.** Stir again thoroughly.



**6.** The oil is highly pigmented because some of the pigment is also rubbed off when the excess is wiped off\*.



**7.** The oil should have been absorbed by the surface for at least 20 minutes. Then remove any excess with a lint-free cloth.



**8.** Before treatment, the wood is brushed to obtain a fine grain. A uniform finish is obtained by applying a second thin coat of oil, then treated as in step 7.

*\* Small quantities of pigments can be used on interior surfaces. However, for exterior applications, a minimum percentage of pigments is required for UV protection. See product information.*